



Lift/Tilt Jib Operating Instructions

1. Make sure forklift is operated ONLY by a trained and certified forklift driver.
2. Drive forklift forks fully into the Lift Jib's fork pockets so that the Lift Jib's fork pockets rest against the back (vertical part) of the forklift forks.
3. Wrap safety chain around fork carriage and hook back onto itself taking care to remove as much slack from the chain as possible.
4. Raise Lift Jib up to eye level and inspect Lift Jib. Look for broken welds, fatigued steel, bent or broken parts. If any of these conditions exist, do NOT use Lift Jib.
5. Inspect swivel hooks and shackles for wear.
6. Verify screw pins in shackles are threaded all the way in.
7. Extend Lift jib to full extension and inspect extension.
8. Do not exceed the lower of the relevant capacity ratings stated on Lift Jib data label or the forklift data plate.
9. Inspect area of use for obstructions. Extended Jib with products will require wider turning radius.
10. Raise item off ground just enough to move it. The lower the center of gravity the better.
11. Drive at slow & safe speeds. Use someone as an assistant to spot and guide.

