



# Assembly Instructions

## Model MBN-9048

### Step 1



Remove all packaging and inspect for damage.

### Step 2



Find hardware bag containing (4) 3/8" x 3.5" bolts and (8) 3/8" x 2" bolts and lock nuts. 9/16" wrench needed.

### Step 3



Place end rail into sockets.

### Step 4



Place opposite end rail into sockets.

### Step 5



Open Right Side Rail.

### Step 6



Open Left Side Rail.

### Step 7



Bolt end rails to pocket sockets using (8) 3/8" x 2" bolts and lock nuts.

### Step 8



Bolt Side Rails using (4) 3/8" x 3.5" bolts and lock nuts.

### Step 9



Once all bolts are tightened using 9/16" socket or wrench, inspect basket for complete assembly before using.