

Operating Instruction

PTZ-2500ES

HYDRAULIC HAND PALLET TRUCK



PTZ-2500ES Scale Hand Pallet Truck

Parts List

PART NO.	DESCRIPTION	QTY	PART NO.	DESCRIPTION	QTY
1	SNAP-RING	1	69	CHAIN JOINT	2
2	SPRING CAP	1	70	CHAIN	1
3	SPRING	1	71	RELEASE ROD	1
4	PUMP PISTON	1	72	LEVER	1
5	DUST SEAL	1	73	SPRING PIN	1
6	PUMP CYLINDER	1	74	NYLON ROLLER	1
7	Y-RING	1	75	SPRING PIN	1
8	NYLON SLEEVE	1	76	RUBBER WASHER	1
9	COPPER WASHER	1	77	HANDLE	1
10	VAVLE BODY	1	78	SPRING PLATE	1
11	BUSHING	2	79	SPRING PIN	2
12	SCREW	1	80	SPRING PIN	1
13	COPPER WASHER	1	81	BUSHING	2
14	SPRING	1	82	TABLE PIN	2
15	PIN	1	83	LIFTING YOKE	1
16	STEEL BALL	1	84	SPRING PIN	2
17	HIGH PRESS VALVE HOUSING	1	85	BUSHING	2
18	COMPEN SATORY SPRING	1	86	BUSHING	2
19	O-RING	2	87	ROD	2
20	COPPER WASHER	2	88	WASHER	4
21	PIN	1	89	BUSHING	4
22	SPRING PIN	2	90	BUSHING	4
23	BEARING CAP	1	91	SHAFT	2
24	BEARING	1	92	BUSHING	4
25	TABLE	1	93	SPRING PIN	2
26	SNAP-RING	1	94	ARM	2
27	SPRING PIN	1	95	SNAP-RING	4
28	STEEL BALL	1	96	LOAD WHEEL SHAFT	4
29	RELEASE VALVE HOUSING	1	97	PLATE	4
30	SPRING	1	98	BEARING CAP	8
31	O-RING	1	99	LOAD WHEEL	4
32	RELEASE NOZZLE	1	100	SPRING PIN	4
33	CAM	1	101	BOLT	4
34	SCREW	1	102	COVER	1
35	NUT	2	103	BOLT	4
36	WHEEL SHAFT	1	104	ELECTROPLAX	1
37	BEARING	4	105	LINK BOX	1
38	WHEEL (PU \RUBBER\NYLON)	2	106	FORK	1
39	SNAP-RING	2	107	SPRING PIN	1
40	WHEEL CAP (NYLON WHEEL)	2	108	SCREW	8
41	SNAP-RING	2	109	PRESSORECEPTOR	1
42	ROLLER PIN	1	110	WASHER	4
43	BUSHING	1	111	WASHER	4
44	ROLLER	1	112	SPRING PIN	4
45	HANDLE STAND	1	113	ARM SHAFT	2
46	SPRING PIN	1	114	SCALE	1
47	HANDLE PIN	1	115	SCREW	4
48	PLUG	1	116	DIPLAYER STAND	1
49	O-RING	1	117	BOLT	3
50	PLUG	1	117-1	NUT	6
51	SPRING	1	118	DIPLAYER	1
52	VALVE	1	119	V-NUT	1
53	SCREW	2	120	V-NUT	2
54	SPRING WASHER	2	121	BOLT	2
55	OIL BOX CAP	1	122	STAND	1
56	OIL BOX PLUG	1	123	SCREW	1
57	O-RING	1	124	BOLT	4
58	OIL BOX	1	125	CAP	1
59	Y-RING	1	126	SHAFT	1
60	O-RING	1	127	SPRING PIN	1
61	HYDRULIC CYLINDER	1	128	BOLT	2
62	O-RING	1	129	V-NUT	2
63	DUST SEAL	1	130	AMP METER	1
64	PISTON	1	131	CHARGE	1
65	STEEL BALL	1	132	BATTERY	1
66	BOLT	3	133	PLATE	1
67	SPRING WASHER	6	134	NUT	1
68	ANCHOR BOLT	1			



