



Koke Rescue Basket



OWNER'S MANUAL



KOKE MBR Series

Basic Operating Instructions

1. Follow all standard rigging and crane procedures.
2. Use a 4-point bridle capable of supporting, at least five times the total load applied or transmitted to it.
3. When a wire rope bridle is used, eyes in the bridle must be fabricated with thimbles.
4. Bridle must be attached to the basket with screw pin alloy shackles.
5. Proof test lift must be performed prior to hoisting personnel.
 - a. Connect test weight weighing at least 125% of rated capacity of basket.
 - b. Hoist basket off ground for a minimum of five minutes.
 - c. Lower and inspect basket and rigging for any defects that pose a safety hazard.
 - d. If any safety hazards are detected, basket must not be used.
6. Trial lift must be performed immediately prior to each shift or after repositioning of equipment.
 - a. Perform trial lift with test weight attached and no personnel by performing a lift to all intended work positions.
7. Basket is ready to be used.
8. Access gate must be closed and latched while during all lifts.
9. Personnel must keep both feet on floor of basket at all times.
10. All personnel are required to wear a full-body harness with lanyard.
11. For full disclosure see OSHA Regulations 29CFR1926.1431, 29CFR1926.502 & ANSI B56.1

