



# STRIP DOOR INSTALLATION WORKSHEET

NOTE: THESE INSTRUCTIONS ASSUME THE INSTALLER IS FACING THE BUILDING.

### SUGGESTED FASTENING METHODS

#### CONCRETE BLOCK OR BRICK WALL:

3/4" x 3" ONE-PIECE ANCHOR WITH  
EXPANSION COLLAR

#### METAL SIDING BUILDING:

INSIDE THROUGH BOLT MUST BE USED.  
(BACKUP PLATE MAY BE NECESSARY)

### INSTALLATION TYPE

- DOOR JAMB MOUNT (ANGLE MOUNT)
- SURFACE MOUNT (WALL OR FLAT MOUNT)
- OFF-THE-WALL MOUNT
- TRACK WALL MOUNT

### TYPE OF MATERIAL

- STANDARD
- USDA
- RIBBED
- WELD SCREEN

### MATERIAL WIDTH x OVERLAP

- 6" x 2"
- 8" x 2"
- 8" x 4"
- 12" x 2"
- 12" x 4"
- 12" x 6"
- 16" x 4"
- 16" x 6"
- 16" x 8"

### MOUNTING BRACKET

INSTALL MOUNTING BRACKET WITH ENCLOSED FASTENERS. ASSEMBLE BRACKET WITH ARROWS FACING EACH OTHER IF MORE THAN ONE PIECE IS PROVIDED.


### STRIP OVERLAP

THE STRIP MATERIAL HAS A SLIGHT CURVATURE WHEN HUNG. SEE ILLUSTRATION FOR PROPER INSTALLATION TO INSURE A TIGHT SEAL.

A-OVERLAPPED SURFACE B-NON-OVERLAPPED



NOTE: A DOT WAS PLACED ON THE STRIPS TO INDICATE THE CURVATURE. WHEN INSTALLING THE STRIPS, THE DOTS MUST FACE EACH OTHER.



MOUNTING BRACKET WIDTH \_\_\_\_\_

NUMBER OF STRIPS \_\_\_\_\_

SAFETY STRIPS \_\_\_\_\_

STRIP LENGTH \_\_\_\_\_

LINEAR FOOTAGE \_\_\_\_\_

IF STRIPS ARE DRAGGING ON THE FLOOR AFTER INSTALLATION, TRIM THE STRIPS AT THE BOTTOM